



## TOYOTA PRADO 250 SERIES MY2025 ON SCRUB RAILS

### **IMPORTANT! – READ BEFORE INSTALLATION**

- This product must be installed exactly as per these instructions using only hardware supplied.
- Take a few moments to read instructions thoroughly before beginning work.
- In the event of damage to any bar component please contact OFFROAD ANIMAL to arrange repair/replacement of components.
- Do not use this product for any vehicle make or model other than that specified on these instructions.
- Do not remove labels from this product.
- This product and its fixings must not be modified in any way unless stated in these fitting instructions.
- The installation of this product is recommended for trained personnel.
- These instructions are correct at time of publication. OFFROAD ANIMAL cannot be held responsible for the impact of any changes subsequently made by the vehicle manufacturer. If you find something has changed please contact us to let us know!
- During installation it is the duty of the installer to check correct operation/clearances of all components.
- If Instructions are to be printed for reference in the workshop, it is recommended that they are printed in colour, for best legibility.
- Fitting time estimated 1-2 hours

## GENERAL CARE AND MAINTENANCE

Only wash the product with a PH neutral car wash to prevent paint damage and discolouration.

Plastic parts may be maintained with silicone spray.

Do not use acidic or alkaline based cleaning products.

It is important to perform regular checks (pre trip or on an annual basis) on the installed product. Checks include:

- Visual inspection for damage (e.g. cracks, chips, dents etc.)
- Electrical wiring is not rubbing anything or worn out
- Bolts are torqued to correct specification (see torque guide below)

For touching up small stone chips, Offroad Animal recommends the following paint products:

- Dupli-Color Trim & Bumper Paint Black (TB101)
- VHT Hood, Bumper & Trim Paint Black (SP27)

## BOLT TORQUE SETTINGS

Use the following bolt torques on all general fasteners, unless otherwise specified.

GENERAL FASTENERS	
Size	Torque Nm
M5	5 Nm
M6	9 Nm
M8	22 Nm
M10	44 Nm
M12	77 Nm

Use the following bolt torques on all structural front bar mount and tow point fasteners, and rear towbar fasteners, unless otherwise specified.


FRONT BAR MOUNTS AND TOW POINTS + REAR TOWBAR	
Size	Torque Nm
M10	57 Nm
M12	100 Nm
M14	164 Nm
M16	248 Nm

**Always use a torque wrench to set correct torque settings. Ensure torque wrench is set to Nm unit of measurement. Otherwise perform conversion to lb-ft.**

## PARTS LISTING

**IMPORTANT:** Check all parts are present before beginning work! Contact OFFROAD ANIMAL if something is missing.

### Main Parts – In the Box

Qty	Part Number	Description	Image
1	SR-TPR-250-25-ASM1L	Toyota LC250 Side Rail Main Assy	
1	SR-TPR-250-25-ASM1R	Toyota LC250 Side Rail Main Assy	
1	SR-TPR-250-25-ASM2L	Prado 250 Side Rail Spigot Assy	
1	SR-TPR-250-25-ASM2R	Prado 250 Side Rail Spigot Assy	
1	B-1683L	LC250 Side Rail Front Trim Bracket	
1	B-1683R	LC250 Side Rail Front Trim Bracket	
2	T-0170	Crush Tube 67mm 16x1.6mm	
2	M10 Saddle Washer	Black Nylon Saddle Washer	
2	PW-P-14X9-180	Pinch Weld - Plain 14X9MM, Rubber, 180mm Length	N/A

**Small Parts – Contained in Small Parts Kit Bag**

Qty	Part Number	Description
<b>2</b>	M10 FW LHD BLACK ZINC	WASHER, FLAT M10X28.5X2.5, ISO4042 ZnNi BLACK PASSIVATED FINISH
<b>2</b>	M10X100 BHCS BLACK ZINC	SCREW, BUTTON HEAD CAP, M10X100X1.5 GR12.9, ISO4042 ZnNi BLACK PASSIVATED FINISH

## TOOLS REQUIRED

The following tools will be required to install the product.

Hand Tools	Power Tools	Workshop Equipment
16mm Metric Socket / Spanner 5+6mm Hex (Allen) Key  Centre Punch  Deburr Tool  Side Cutters	Electric Drill  6mm Drill Bit  Step Drill (6-18mm min. range)  Electric/Air Impact Driver (Optional)	Masking Tape  Marker Pen  Workshop Rag  Paint Pen/Rust Inhibitive Paint


## WORKSHOP SAFETY

It is the responsibility of the installer to always complete works in a safe manner. Make sure the following safety equipment is available and precautions are observed whilst fitting this product.


<p>Hearing Protection</p> 	<p>Always wear ear protection when using power tools.</p>
<p>Eye Protection</p> 	<p>Ensure eye protection is always worn when cutting or drilling.</p>
<p>Manual Handling</p> 	<p>Do not attempt to lift bar assemblies or rock sliders on your own.</p> <p>Always use two people to lift or use mechanical Lifting aid such as hydraulic lifting trolley.</p>
<p>Vehicle Support</p> 	<p>Always ensure vehicle is properly supported when working on it. Do not attempt to fit products whilst suspension work is being carried out. Do not work under a vehicle supported only by a jack.</p>



<ol style="list-style-type: none"><li>1. Offroad Animal Toro Bar (Part No. <b>FB-TPR-250-25-TOR-ASM0</b>) and Steel Rock Sliders (Part No. <b>RSW-TPR-250-25-ASM0</b>) must be fitted to the vehicle prior to fitment of these scrub rails.</li><li>2. These scrub rails are not compatible with any other variants of rock sliders and front bars.</li></ol>	<b>TOOLS REQUIRED</b>
	<b>FASTENERS</b>




<ol style="list-style-type: none"><li>3. If fitting scrub rails to a vehicle with existing Toro bullbar and slider fitment, remove the slider end caps from the rock sliders. Follow the fitment steps in reverse on the slider instructions.</li><li>4. If fitting scrub rails to vehicle at the same time as Toro bullbar &amp; sliders install products in the following order  1<sup>st</sup> - Toro Bull Bar 2<sup>nd</sup> – Rock Sliders 3<sup>rd</sup> – Scrub Rails</li></ol>	<b>TOOLS REQUIRED</b>  5mm Hex Key
	<b>FASTENERS</b>  Supplied with Rock Slider Kit




5. Due to where the side rail tube attaches to the Toro bar, the end spigots are handed.
6. The spigots have a notch cut into the profiled edge. This notch should face upwards when installed.
7. Identify the correct spigots for each side rail and place with the rail.
8. It can be helpful (but is not necessary) for the dry fit to attach the spigot to the captive nut in the end of the slider assembly, using a short M10 bolt.


**TOOLS REQUIRED**

Short M10 Bolt (not supplied)





	<p><b>TOOLS REQUIRED</b></p> <p>Masking tape 16mm Socket / Spanner</p> <p><b>FASTENERS</b></p>
<p>13. Apply masking tape to the toro bullbar tube in the area where the scrub rail will join, as indicated in diagram above.</p> <p>14. Align the scrub rail with the vehicle to perform a dry test fit. Manipulate the position of the scrub rail to achieve the target alignment. Scrub rail should be</p> <ul style="list-style-type: none"> <li>- Approx 20mm clearance to the vehicle body.</li> <li>- Parallel to the top face of the bull bar.</li> </ul> <p>Ensure the end spigot is included between the end of the side rail and the toro tube, either with the optional bolt, or held in position by an assistant.</p> <p>15. Once happy with position, snug the M10x35 bolts at the rock slider -&gt; side rail interface just tight enough to prevent the side rail tube from moving.</p>	







**RHS SHOWN**

**Note: Image from different vehicle fitment, illustrative of procedure**

<ol style="list-style-type: none"><li>17. Remove the scrub rail and spigot from the vehicle.</li><li>18. Hold the spigot back up against the Toro bar by hand (Taking care to ensure the alignment notch is facing up) and align with the outline traced earlier.  Mark the position of the hole in the center of the spigot onto the Toro bar with a pen or scribe.</li><li>19. Use a center punch to mark the hole location on the Toro bar tube. It can be helpful to use a square to keep the center punch square to the tube.</li></ol>	<b>TOOLS REQUIRED</b>  Marker Pen Centre Punch
	<b>FASTENERS</b>

	
<p>20. Drill 6mm pilot hole through both sides of the Toro tube at the centre punch location. It is a good idea to use a rag over the car to protect from metal swarf.</p> <p>21. Take care to ensure the drill always remains perpendicular to the tube, so that the hole is aligned in the direction of the spigot/scrub rail.</p>	<p><b>TOOLS REQUIRED</b></p> <p>Electric Drill 6mm Drill Bit Workshop Rag</p> <p><b>FASTENERS</b></p>





25. Fit supplied pinch weld around the curved edge of the spigot. Trim with side cutters as required.

Ensure the pinch weld is pushed all the way onto the edge of the spigot.

**TOOLS REQUIRED**

Side Cutters

**FASTENERS**


--	--



**RHS SHOWN**

**Note: Image from different vehicle fitment, illustrative of procedure**

26. Loosely position the spigot with the Toro bar and hold in place with 1x M10x100 black button head, flat washer, nylon saddle washer and crush tube, through the 18mm drilled hole in the bar.	<b>TOOLS REQUIRED</b>
	<b>FASTENERS</b>  1x M10x100 black button head 1x M10 black flat washer 1x M10 nylon saddle washer 1x crush tube



27. Refit the scrub rail to the rock slider, using the same procedure as earlier.
28. Secure the scrub rail to the spigot/Toro bar with the M10x100 button head bolt into the embedded nut on the flat end of the scrub rail.
29. Re-check and adjust alignment between scrub rail, rock slider and Toro bar. Ensure 20mm clearance to the vehicle body is still maintained.
30. Once happy with alignment, tighten bolts in the following order.
  - Snug tight M10x35 bolts to prevent tube from moving.
  - Tighten M10x100 Spigot Bolt.
  - Progressively tighten M10x35 Bolts, one turn then alternate, until the nut plate fully bottoms out.

#### TOOLS REQUIRED

6mm hex/Allen key  
16mm Socket / Spanner

#### FASTENERS



<ol style="list-style-type: none"><li>31. Fit the Front Trim Bracket to the captive threads in the rock slider. Secure with M8x20 Black Button head bolts and M8 Black Flat Washers.</li><li>32. Complete the entire scrub rail install again for the other side of the car.</li><li>33. After that you are done!</li></ol>	<b>TOOLS REQUIRED</b> 5mm Hex / Allen key
	<b>FASTENERS</b> 2x M8x20 black button head 2x M8 black flat washer



**Congratulations!**  
**Head for the tracks and enjoy your newly protected Prado!**